

# Sharps Safety Activation



Always properly engage the safety mechanism on frequently used devices.

## Why:

- Needle sticks are on the rise.
- There is an increased risk to exposure.
- Scan the QR code to watch a video on preventing needle sticks.



## Procedure:

- Always use the hand holding syringe to engage the safety.
- Push the safety forward until you hear the click.
- Dispose of used needle into a Sharp's receptacle.
- Never dispose of a needle in the trash.

## Remember:

- One-hand click

